


# HIMO-01P Pin List



## Power

USB5V: nothing to connect. as NC.  
VIN : connect to MIC5219-3.3; input 3.4V-5V.  
3.3V : MIC5219's output (max 500ma)

## Other

SIZE :59.69\*26.67mm  
HOLES: diameter 2.1mm

## Notice

If you use HIMO-01M, you will use pins such as RX, TX,RST,Wake.  
If you use HIMO-01, you will use pins such as MOSI, MISO,SCK,CS,NRST,DIO0-5.  
You also need to install 6 configuration resistors

## Wireless

LoRa: HIMO-01 or HIMO-01M(default)  
PA : 20dBm  
ISM : 410-470Mhz  
ANT : +5dB